


**CRAFTSMAN 13 mm (1/2 in.)
19.2 VOLT CORDLESS DRILL-DRIVER
MODEL NO. 973.227050
REPAIR SHEET**

**CRAFTSMAN 13 mm (1/2 in.), 19.2 VOLT CORDLESS DRILL-DRIVER
MODEL NUMBER 973.227050**


The model number will be found on a label attached to the engine housing. Always mention the model number in all correspondence regarding your **13 mm (1/2 in.), CORDLESS DRILL-DRIVER** or when ordering repair parts.



PARTS LIST

KEY NO.	PART NUMBER	DESCRIPTION	QTY.
1	6613401	Screw (Special).....	1
2	6903318	Chuck (Item No. 9 75188).....	1
3	1323518	Battery Pack	1
4	1425302	Charger	1
5	3063616	Carrying Case (Not Shown)	1

CRAFTSMAN 13 mm (1/2 in.), 19.2 VOLT CORDLESS DRILL-DRIVER – MODEL NUMBER 973.227050




CRAFTSMAN 13 mm (1/2 in.), 19.2 VOLT CORDLESS DRILL-DRIVER – MODEL NUMBER 973.227050

The model number will be found on a label attached to the engine housing. Always mention the model number in all correspondence regarding your **10 mm (3/8 in.), CORDLESS DRILL-DRIVER** or when ordering repair parts.

PARTS LIST

KEY NO.	PART NUMBER	DESCRIPTION	QTY.
1	984612001	Housing Assembly.....	1
2	3000909	Top Level	1
3	540352003	Gear Change Button	2
4	6620311	Screw (M3 x 20 mm)	4
5	6359801	Mounting Plate	1
6	6399201	Detent Clips.....	2
7	5434601	Spring Holder	1
8	4011802	Clutch Cap	1
9	5437201	Sleeve.....	1
10	6843401	Spring.....	1
11	6711101	Washer	2
12	6838001	Clutch Washer	1
13	6721901	Steel Ball	6
14	6833802	Pin	6
15	984613001	Motor w/Gear Train and Clutch.....	1
16	2701298	Switch Assembly.....	1
17	540340006	Foward-Reverse Selector.....	1
18	3048003	Rear Level.....	1
19	9002724	Wrist Strap.....	1
20	6620805	Screw (M4 x 16 mm)	9
21	6627201	Screw (M4 x 14 mm)	1
22	630206007	Bit Clip.....	2
23	6622306	Screw (M3.5 x 11.5 mm)	1
24	983000198	Operator's Manual	

3-4-13
(Rev:02)



WIRING DIAGRAM